

HIS Push-Fit Filter

Installation and Conditioning Instructions



Parts & Service Availability:

Important – Always use genuine Doulton® replacement filter elements and components to guarantee the manufacturer's performance claims.

Contact your local Doulton® distributor for sales, service, replacement parts and for the range of available replacement filter elements.

1. Installation

Note – The filter cannot be used for the treatment of hot water and should only be connected to the cold water supply.

1.1 Selecting a Position for the Filter

The filter should be fixed inside a unit or to a wall with the screws and bracket provided, near to the incoming water supply and the user tap. Make sure that the filter is located so that the connecting pipework does not have any sharp bends in it. **For easy servicing of the filter there should be at least 4 inches of clearance below the body of the filter** to allow for removal of the filter element for cleaning or renewal.

1.2 Connecting Pipework & Fittings

The filter is supplied with 3/8" (inch) pushfit connections. Medium density polyethylene tubing is recommended.

Important - Tubing must conform to the following tolerances:

Tubing Dimensions:

Head Type	Nominal	Tolerance	
		+	-
3/8"	3/8"	.001"	.004"

An isolation valve and non-return valve should be fitted upstream of the filter (these are required by law in the UK). The isolation valve may be used to regulate the maximum flow rate in accordance with the requirements of the filter element used.

Having selected the appropriate fittings, a user tap should be installed in accordance with the manufacturer's instructions in a convenient position and then connected to the filter.

1.3 Assembling and Fixing the Filter

Fit the bracket to the filter head using the 4 retaining screws provided and then having chosen a position for the water filter, mark the position of the bracket fixing screws onto the wall/unit.

Attach the filter head to the wall/unit with the 2 fixing screws provided.

With the water supply isolated connect the upstream and downstream pipework to the filter head ensuring that the arrow on the top of the head is showing the correct direction of flow and that piping/fittings are pushed into the push fittings to a minimum of 18mm (.75") depth.

Ensure that a sealing washer is fitted onto the filter element threaded mount stem and screw the filter element into the filter head until washer resistance is felt. Do not over-tighten.

If there is less than 10 inches clearance below the base of the filter housing, place the filter body in position over the filter element before screwing the filter element into the head.

Moisten the O ring on the filter body, check that it is located correctly and then screw the filter body to the filter head. Hand tighten only.

2. Conditioning the Ceramic Filter

The filter system should now be ready for pressurisation. With the user tap in the on position, gradually open the upstream isolation valve until the flow from the tap has stabilised at the recommended flow rate.

Close the user tap and ensure that the system is watertight.

In order to remove any loose particles resulting from the manufacturing process or from cleaning the filter element, it is recommended that the first supply of filtered water should be run to waste for 10 minutes.

For a new filter element, the maximum flow rate will be achieved once the ceramic filter element has become fully saturated; to allow the filter element to be conditioned to the source water, allow the filter to stand for 24 hours and then flush for a further 10 mins to waste.

The filter is now ready for use.

Due to filtration of particulate contaminants from the water during use, the flow of the water from the filter may deteriorate over a period of time. To restore the water flow to its normal level, simply remove, clean and replace the filter element as follows:

3. Servicing the Filters

It is important to wear rubber gloves or wash your hands thoroughly before and after servicing the filter and filter element.

Removal, cleaning and reinstallation/replacement of the filter element is carried out as follows:

With the upstream isolation valve turned off, vent any pressure by opening the user tap.

Place a bowl of under the filter body and unscrew the filter body, which will be full of water. Lower the body into the bowl. The filter element can now be unscrewed from the filter head and cleaned in accordance with the manufacturer's instruction or replaced as described in Section 1.3.

When the filter element have been re-installed, wipe the filter housing clean with a damp cloth and refill the filter system as described in Section 2.

Cleaning/Sterilising the System

To clean the housing wipe externally with a warm damp cloth. The following substances should be avoided:

- Strong oxidising agents such as bleach or Milton solution
- All strong acidic materials including some descalents
- Strong alkaline material

A filter element that has reached the end of its life would be indicated by a reduction in the taste quality of the filtered water. The filter element should be replaced in accordance with the rated service capacity, which would typically give a period of six months usage.

Manufactured by:

Doulton Water Filters, Newcastle, Staffordshire, ST5 9BT, United Kingdom.

Telephone: +44 (0) 1782 664420
Fax: +44 (0) 1782 664490
Email: filtersales@doulton.com
Website: www.doulton.com

Doulton® is a trademark registered to Fairey Industrial Ceramics Limited.

